



INSTALLATION INTRUCTIONS

RHINO! CHARGER RC2 BULL BAR PART NUMBER 5565T, 5565PS, 55645T, 5565211T

2010-2016 DODGE RAM 2500HD & 3500HD 2/4WD

(Not compatible with ParkSense® Front Park Assist)

PACKING LIST

<u>QTY</u>	<u>PART DESCRIPTION</u>	<u>QTY</u>	<u>PART DESCRIPTION</u>
8	3/8" X 1" HEX BOLT	8	3/8" HEX NUT
4	3/8" X 2" HEX BOLT	1	DRIVER SIDE BRACKET
12	3/8" FLAT WASHER	1	PASSENGER SIDE BRACKET
8	3/8" LOCK WASHER	1	RHINO CHARGER BULL BAR

TOOLS REQUIRED

STANDARD & METRIC SOCKET SET

STANDARD AND METRIC WRENCH SET

RATCHET & RATCHET EXTENSION

APPROXIMATE INSTALLATION TIME: 45 MINUTES

IMPORTANT INSTALLATION NOTES AND SUGGESTIONS

READ THE ASSEMBLY AND INSTALLATION INSTRUCTIONS COMPLETELY AND VERIFY THAT ALL THE PARTS LISTED ARE ACCOUNTED FOR. IF YOU HAVE DEFECTIVE, MISSING OR DAMAGED PARTS OR NEED ASSISTANCE, PLEASE CONTACT GO RHINO PRODUCTS FOR FAST, FRIENDLY CUSTOMER SERVICE AT: (888) 427-4466 OR EMAIL: sales@gorhino.com

TO MAINTAIN AND CARE FOR THIS PRODUCT, KEEP IT CLEAN AND DO NOT USE ABRASIVE CLEANERS OR POLISH WAXES.

TEXTURE PAINTED FINISH: MILD LIQUID DETERGENT MAY BE USED. **POLISHED STAINLESS & SEMI GLOSS PAINTED FINISHES:** WE RECOMMEND USING ONLY NON-ABRASIVE AUTOMOTIVE WAX SUCH AS PURE CARNUBA TO AVOID SCRATCHES AND RUST.

INSTALLATION INSTRUCTIONS

STEP-1 BEGINNING WITH THE DRIVER SIDE, LOCATE THE HOLES IN THE FRAME. **PHOTO #1**

STEP-2 POSITION THE DRIVER SIDE BRACKET AS SHOWN AND ATTACH THE BRACKET TO THE FRAME USING (2) 3/8" X 1" HEX BOLTS, FLAT WASHERS, LOCK WASHERS AND HEX NUTS. DO NOT TIGHTEN. **PHOTO #2**

REPEAT THE STEPS TO INSTALL THE PASSENGER SIDE BRACKET.



NOTE: IF YOUR VEHICLE IS EQUIPPED WITH FACTORY TOW HOOKS, REMOVE ONLY THE (2) TOW HOOK BOLTS CLOSEST TO THE CENTER OF THE VEHICLE. POSITION THE BRACKETS OVER THE TOW HOOKS AND ATTACH THE BRACKETS AND TOW HOOKS TO THE FRAME USING THE 3/8" X 2" HEX BOLTS, WASHERS AND NUTS SUPPLIED. **PHOTO #3**



STEP-3 POSITION THE RHINO CHARGER BULL BAR MOUNTING TABS BETWEEN THE DRIVER AND PASSENGER SIDE BRACKETS AND ATTACH THE TABS TO THE BRACKETS USING (2) 3/8" X 1" HEX BOLTS, FLAT WASHERS, LOCK WASHERS AND HEX NUTS. **PHOTO #4**

STEP-4 ALIGN THE RHINO CHARGER BULL BAR AND BRACKET ASSEMBLY WITH THE FRONT OF THE VEHICLE, AND TIGHTEN ALL NUTS AND BOLTS. **PHOTO #5**

