

## **CONTROLLED**

## 43234 Pioneer Worklight Bracket

Place these instructions in the vehicle's glove box after installation is complete.

Important: Please read these instructions carefully prior to installation. Please refer to your fitting instruction to ensure that the alloy tray is installed correctly. Check the contents of this kit before commencing fitment and report any discrepancies.

ltem	Component Name	Qty	Part No.
1	Universal LED Single Bracket	1	CA1734
2	M6 x 16 Hex Bolt	2	B168
3	M6 x 25 Hex Bolt	2	B067
4	M6 Spring Washer	2	W004
5	M6 Flat Washer	2	W031
6	M6 Channel Nut	2	N002
7	Fitting Instructions	1	R1033
Tools Required			



## Tools Required

13mm Spanner





**1A** Assemble the bracket onto front or rear of the tray as shown below. Tighten and proceed to step 2.



**1B** Assemble the bracket onto the side of the tray as shown below. Tighten and proceed to step 2.



