

## Interior Speaker/Light Mount

2021+ BRONCO

BRSB-01



### TOOLS REQUIRED

- #5 Allen Head

### SKILL LEVEL

- Novice/Intermediate  
- 1 persons

Little skill level required, you can easily install it by yourself.

### TIME REQUIRED

- .5 Hour

Time to install this should approximately take .5 hour.

## WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner’s manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.  
Customer Service: 855-680-9595

*DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.*

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

• Always wear eye protection when operating power tools

*Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information*

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



# INSTALLATION MANUAL

## STEP 1

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. **This can be installed with and without a top, however removal of the top will allow install to be much faster.**


**Hardware Included:**

- (4) M8x25mm Bolts
- (4) M8 Flat Washers
- (4) M8 split Washers



## STEP 2

Locate the four M8 factory mounting holes on top of the rear roll cage.



# INSTALLATION MANUAL

## STEP 3

Hold up your speaker bar, and using your #5 allen head and provided hardware, loosely install speaker bar.



# INSTALLATION MANUAL

## STEP 4

Ensure speaker bar is straight and centered, and secure hardware.



# INSTALLATION MANUAL

## STEP 5

When mounting items, use the provided rubber grommets on the bar to run wiring as needed.



## STEP 6

Double check all hardware and wiring is secure.

