

Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado

SAFETY

Your safety and the safety of others is very important.

- In order to help you make informed decisions about safety, we have provided installation instructions and other information.
- These instructions alert you to potential hazards that could hurt you or others.
- Please do a job safety analysis before each task to identify potential hazards for your situation and remove/protect against them.
- You must use your own good judgment, and take your time.

Read and understand all safety precautions and instructions before installing this product.

THIS PRODUCT IS FOR OFFROAD USE ONLY. ALL LIABILITY FOR INSTALLATION AND USE RESTS WITH THE OWNER.

CARELESS INSTALLATION AND OPERATION CAN RESULT IN SERIOUS INJURY OR EQUIPMENT DAMAGE.

Injury hazard

Failure to observe these instructions could lead to severe injury or death.

- Always remove jewelry and wear eye protection.
- ❑ Always use extreme caution when jacking up a vehicle for work. Set emergency brake and use tire blocks. Locate and use the vehicle manufacturers designated lifting points. Use jack stands.
- Always use appropriate and adequate care in lifting components into place.

- □ Always insure components will remain secure during installation and operation.
- Always wear safety glasses when installing this kit. A drilling operation will cause flying metal chips. Flying chips can cause serious eye injury.
- Always use extreme caution when drilling on a vehicle. Thoroughly inspect the area to be drilled (on both sides of material) prior to drilling, and relocate any objects that may be damaged.
- **Always use extreme caution when cutting and trimming during fitting.**
- **Always tighten all nuts and bolts securely per installation instructions.**
- Always route electrical cables carefully. Avoid moving parts, components that become hot and rough or sharp edges.
- **Always insulate and protect all exposed wiring and electrical terminals.**
- □ Always perform regular inspections and maintenance on mounts and related hardware.



Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado

I. Overview

Congratulations on your new purchase of the industries' best and most stylish front bumper available for the 2015 Chevrolet Colorado. This bumper has been designed to be lightweight and easily customized with the industry's highest quality accessories.

Your front bumper designed in 3-D from digitized data, CNC laser cut, fabricated, and powder coated... all in the U.S.A.

Enjoy the fit and finish of a quality 2015 Chevrolet Colorado Bumper from Fab Fours Inc.





Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado

Parts List

- D325X replacement bumper
- 50045-HW fastener kit
- Instruction manual

Tools Required

- Socket wrench with extension (ratcheting wrenches may also be convenient)
- 7mm, 8mm, 9mm, 10mm, 15mm , and 5/8" sockets and box end wrenches
- 7/16" wrench and 7/16" ratchet wrench
- Electric Drill with 5/16" drill bit
- T15 torx
- Hex key sets
- Flat head screw drivers
- Floor jack and wood block.

II. Removal of OEM Bumper

Note: Save all OEM parts until installation is complete!

- A. Disconnect the battery prior to removing the OEM bumper. This will ensure that no sensors are triggered during bumper removal.
- **B.** Remove 6 torque screws using a T15 torx from under the hood attaching the grille.



Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado



Figure 1

C. Remove 8 torque screws and 11 pop-pins each fender well. Pry back the black plastic fender well.



Figure 2



Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado

D. Using a 15mm socket or wrench to remove 4 bolts attaching the skid plate to the bumper.



Figure 3

- E. Using a 10mm socket remove 2 bolts on the bottom of bumper.
- F. Use a pin popper to remove 4 clips and 10 clips to detach the grille.
- G. Using a 15mm socket remove 4 bolts holding the impact bar.
- H. Remove the tow hooks with an 18mm socket or wrench.



Installation Instructions Vengeance Front Bumper Product Number: D3351, D3352

Application: 2015 Chevrolet Colorado



Figure 4



Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado

III. Pre-Installation: Valence Installation

NOTE: The following installation steps apply to the installation of the front bumper. PLEASE READ THE ENTIRE MANUAL BEFORE ATEMPTING INSTALLATION. Ignoring these steps will increase your probability of scratching the vehicle during product installation.

- A. Remove the bumper and valence from the shipping carton. Lay all items out on a blanket to prevent damage to the powder coating.
- B. If you are installing aftermarket lights, do the wiring for those now. (But don't install or plug them in until after bumper is installed.)
- C. Using a marker and the provided hardware loosely bolt the valence mounting brackets to the valence (ref 5a). Position the valence on the truck and have another person hold it in place (ref 5b-c). At this point, reaching underneath the valence, adjust the valence mount so that it is flush against the plastic surface and mark the drill location on the plastic grill mount, indicated in figure 4c. TAKE CARE TO MAKE SURE VALENCE AND VALENCE MOUNT ARE PROPERLY POSITIONED AS THIS WILL EFFECT FINAL FITMENT.
- D. Remove valence and drill hole with 5/16" drill in marked spot (ref 5c)



Vengeance Front Bumper Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado



Figure 5a (valence loosely bolted to valence mount)



Figure 5b (valence position relative to fender)



Installation Instructions Vengeance Front Bumper Product Number: D3351, D3352

Application: 2015 Chevrolet Colorado



Figure 5c (valence position relative to grill)



Figure 5d (mount point on plastic grill mount)



Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado



Figure 5e (mount points on fender)

- E. Pulling wheel well liner back, place valence in position (ref 5b), with another person holding valence in place, run bolts up through holes indicated by the triangles in Figure 5d. Hand tighten bolts.
- F. Line up valence mount with previously drilled hole, insert bolt, and hand tighten (ref 6a-b).
- G. Using a 7/16 wrench and ratchet wrench, tighten bolts running through the fender. Once valence is positioned properly at grill, tighten bolts running through valence mount (ref 6c).



Vengeance Front Bumper Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado



Figure 6a (wheel well liner pull back)



Vengeance Front Bumper Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado



Figure 6b (bolts through mount points on fender)



Installation Instructions Vengeance Front Bumper Product Number: D3351, D3352

Application: 2015 Chevrolet Colorado



Figure 6c (bolts through mount points on valence mount and plastic of grill)



Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado

IV. Front Bumper Installation

- A. Use painter's tape to tape off the valance of your truck to help prevent scratching the paint.
- B. Using the supplied hardware and a 15mm ratchet wrench, mount the bumper to your truck but do not fully tighten. There will be 4 OEM bolts, 2 on each side.



Figure 7a (frame mount plate)



Product Number: D3351, D3352 Application: 2015 Chevrolet Colorado



Figure 7b (bumper mounted to frame)

- C. Adjust the height of the bumper to the truck and tighten the bolts. (Fab Fours recommends 1/4 profile gap as a standard.)
- **D.** Enjoy your new Vengeance Front Bumper from Fab Fours!