

## A-Pillar Light Mount

2021+ BRONCO

LBBR-02



### TOOLS REQUIRED

- T30

### SKILL LEVEL

- Novice/Intermediate  
- 1 persons

Little skill level required, you can easily install it by yourself.

### TIME REQUIRED

- .5 Hour

Time to install this should Approximately .5 Hour.

## WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner’s manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.  
Customer Service: 855-680-9595

*DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.*

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

• Always wear eye protection when operating power tools

*Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information*

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



# INSTALLATION MANUAL

## STEP 1

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from.



## STEP 2

Loosely install the lights onto your brackets using the hardware provided with the lights.

*Note: We are using four 3" DV8 elite pod lights for our install.*



## STEP 3

We installed the lights onto the two outer holes. We left our lights loose so we can access the two front mounting holes on each bracket.



# INSTALLATION MANUAL

## STEP 4

On the passenger side, unscrew the antenna and set off to the side.



## STEP 5

Using a T30 torx bit, remove the two screws on each side of the windshield cowl.



# INSTALLATION MANUAL

## STEP 6

Place the bracket with the lights over the holes and route wire under the cowl towards the hood of the vehicle. Using factory hardware, reinstall the bolts using the T30 torx bit. Ensure bracket is aligned with windshield cowl and tighten until secure.



## STEP 7

Tighten the lights to the LBBR-02 bracket and check to ensure all hardware is secure. Reinstall antenna through passenger side bracket.



# INSTALLATION MANUAL

---

## STEP 8

Double check to ensure all hardware is secure and complete wiring the lights to your preference.

