

## RRUN-01

2020-21 JEEP GLADIATOR 8  
2005-21 TOYOTA TACOMA  
ADJUSTABLE BED RACK



### TOOLS REQUIRED

- 6mm hex head
- 13mm wrench or socket
- 17mm wrench or socket
- T25 torx bit (Gladiator Only)

### SKILL LEVEL

- Novice/Intermediate
  - 1 (you) to 2 persons
- Little skill level required, you can easily install it by yourself however, additional help will be useful

### TIME REQUIRED

- 1 Hour
- Time to install this should only take about an hour

## WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner’s manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.  
Customer Service: 855-680-9595

*DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.*

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

*Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information*

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



# INSTALLATION MANUAL

## STEP 1

Begin by opening up all pieces included and inspecting them prior to install. If you are missing any components or have any questions prior to your install, please contact the company the item was purchased from.

<b>Hardware Included:</b>	(32) M10 Flat Washers
(12) Slide Brackets	(12) M8 Split Washers
(8) D-Rings	(12) M8 Flat Washers
(16) M10 Allen Head Bolts	(12) M8 Nuts
(16) M10 Split Washers	Cut Foam



## STEP 2

Lay down each bedside section and using the provided foam, place the foam onto the bottom side of the section.

*Note: Some sections may need to be trimmed slightly. You can use standard scissors for this.*



# INSTALLATION MANUAL

## STEP 3

You are now ready to mount the side sections to the truck. For both the Gladiator and Tacoma, you will need to have the factory optional slide rails.

*Tacoma:* Remove the end caps for the slide rails by pressing on the face and pulling back.

*Gladiator:* Using a T25 torx bit, remove the front caps on the two side rails.



## STEP 4

Once caps are removed, take 6 of the black slide nuts and insert them into the rails. Position three near the rear, and three in the front with the threads pointing to the center of the bed.



# INSTALLATION MANUAL

## STEP 5

Place the front section (driver or passenger) over the slide bolts, and secure with the provided M8 washers, lock nuts, and nuts. We have included optional D-Rings that can be added to these mounting points. If using the D-Ring, you will want to place this on the slide nut first as shown.



## STEP 6

Continue this same process for the opposite side ensuring that they are equal distance away from the cab.



# INSTALLATION MANUAL

## STEP 7

For the rear sections, move the slide brackets into place so that the rear section on each side is no less than 3 inches from the front section. The distance will depend on vehicle and bed length. The install will be the same as the fronts.



## STEP 8

We included some optional Rotopax mounts with our kit. These are designed to be used instead of the D-Rings, and to be placed on the back two mounts of the rear section. Note: This kit does not include the Rotopax or the Rotopax twist mount.



# INSTALLATION MANUAL

## STEP 9

Once all 4 sections are in place and secure, install the two cross brackets using the provided M10 hardware with the cross bracket with the light opening in the rear. These can be adjusted depending on your setup.

*Note: The optional light to be used in the rear cross bracket is our 6" Single row light (BS6E30W5W).*



## STEP 10

Once the two cross brackets are in place, the last piece to install is the provided (optional) Hilift mounts. Using the remaining M10 hardware, these are designed to be mounted to the outside of the rack with one mount on the front half, and one on the rear. These will be moved and adjusted depending on the size of your Hilift.



# INSTALLATION MANUAL

---

## STEP 11

You are now done with the install of your new DV8 8" Adjustable Rack.

