

IMPORTANT INFORMATION

Warning:

It is important that all roof racks and accessories are installed and attached correctly. Failure to follow the correct attachments could result in an accident, serious injury or death to others. The driver of the vehicle is responsible for securing the roof racks and accessories, checking the attachments, periodically checking bolt torque and visual inspection of all components for wear and damage. Do not attempt to fit the roof rack system or accessory to your vehicle unless you fully understand these fitting instructions. Please direct any questions regarding fitting to the dealer or retailer from where they were purchased.

Maximum carrying capacity: 165lbs (75kg) including the weight of the basket 46lbs (21kg).

Please refer to your vehicle manufacturers handbook for maximum carrying capacity. Always use the lower of the two figures. Load must be evenly distributed over the entire basket.

Use only non-stretch fastening ropes or straps. Ratchet straps are not recommended for use with this basket.

Recommendations: It is essential that all bolt connections be checked after driving a short distance when you first install your roof racks. Bolt connections should be checked again at regular intervals (once a week is enough, depending on road conditions, usage, loads and distances travelled). You should also check the roof racks each time they are re-fitted. Always make sure to fasten your load securely. Please also ensure that all loads are evenly distributed and that the centre of gravity is kept as low as possible and must be entirely contained within the extents of the basket.

The XTray must be removed when putting vehicle through an automatic car wash.

Caution: The handling characteristics of the vehicle changes when you transport a load on the roof. For safety reasons we recommend you exercise extreme care when transporting wind-resistant loads. Special consideration must be taken into account when cornering and braking.

Off-road use:

The XTray may be used in off road applications, however a safety factor of 1.5 is enforced. Please see page 5 for an example on how to calculate the maximum permisible load.

Note for Dealers and Fitters:

It is your responsibility to ensure these fitting instructions are given to the end user or client.

| Rhino-Rack | | |
|--|----------------------------|------------------------|
| 3 Pike Street, Rydalmere, | | |
| NSW 2116, Australia. | Document No: R227 | |
| (Ph) (02) 9638 4744 | Prepared By: Andy Wana | Issue No: 03 |
| (Fax) (02) 9638 4822 | Authorised By: Chris Murty | Issue Date: 29/04/2013 |
| These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended. | | |



XTray Large (RMCB02)













XTray Large (RMCB02)



Important Information

Maximum load capacity :

Maximum permissible load is dependent on the vehicle carrying capacity Please Note: In extreme off road conditions, the load limit

has a built in safety factor of 1.5.

eg. Maximum allowable load is 75kg ÷ 1.5 = 50kg.

Note for Dealers and Fitters:

· It is your responsibility to ensure the instructions are given to the end user or supplier.

Caution:

 \cdot Take note of the change in overall vehicle height, as the addition of the XTray may prevent access to low entrances.

• Bolt connections should be checked at regular intervals (once a week is enough, and is dependent on road conditions, usage, loads and distance travelled).

Maintenance:

- · Bolts should be cleaned and lubricated at regular intervals.
- · Rhino-Rack offers a 3 year Warranty to the original purchaser of the XTray.
- Rhino-Rack cannot be held responsible for incorrect mounting of the XTray or for usage that exceeds production tolerances.
- Make sure to fasten the load securely. Ensure that all loads are evenly distributed in the cargo basket and that the centre of gravity is kept as low as possible.
- · It is recommended that the XTray be cleaned before storing it for extended periods.

